

GPSI-5000: Diagnostic Cable Guide



Link: <https://help.gpsinsight.com/installation-guide/gpsi-5000-diagnostic-cable-guide/> Last Updated: January 4th, 2021

The following guide shows you which vehicles are compatible with GPSI-5000 Diagnostic Cables. (Click to Expand)



*The GPSI-5000 Diagnostic Cable is required for all connected tablet solutions. Hardware is not an option.
*Optional: Customer confirms cable and in-cab location.

GPSI-5000 Diagnostic Cable - Vehicle Guide							
Cable: OBD II Y Pass-thru	Cable: 8-Pin 500K - Type 2 (ELD - 2000D/GPSI-5000)	Cable: 8-Pin 500K - Type 2 (ELD-2000D/GPSI-5000) and Cable: 6-to-9 Pin Conversion	Cable: 8-Pin Threaded (ELD-2000D/GPSI-5000)	Cable: 16-Pin - Hino (ELD - 2000D/GPSI-5000)	Cable: RP1226 (ELD - 2000D/GPSI-5000)	Cable: 16-Pin - Volvo/Mack (ELD - 2000D/GPSI-5000)	Hardware Only
Acura	1997-Present						
BMW	1997-Present						
Chevrolet	1997-Present						
Chevrolet 4500 and up w/ Caterpillar Engine		2001-2017	1997-2000	2018-Present			
Dodge	1997-Present						
Freightliner Cascadia		2004-2019	1995-2003	2019-Present			
Freightliner Coronado/114SD/122SD			1995-2001	2002-Present			
Freightliner Sprinter	1997-Present						
Freightliner All Other Models		2004-Present	1995-2003		2020 - Present (Optional)		
Ford F-550 and Below	1997-Present						
Ford F-650 and Up			1997-2000	2001-Present			
Ford F-650 and Up w/ Cummins Engine			1997-2003				
Ford w/ 7.3L Engine							1997-2004
GMC	1997-Present						
GMC 4500 and Up w/ Caterpillar Engine		2001-2017	1997-2000	2018-Present			
Hino Class 1-5	1997-2009			2010-Present			
Hino Class 6-8		2002-2013	1995-2001	2014-Present			
Honda	1997-Present						
Hyundai	1997-Present						
International w/ 'Y' in Model Number		2009-Present	2001-2008				
International		2001-Present	1995-2000				
Isuzu NPR	2012-Present						1997-2012
Isuzu NPR/NQR	2012-2021	2022-Present					
Kia	1997-Present						
Kenworth			1995-2000	2001-Present	2018 - Present (Optional)		
Mack		2004-2013	1995-2003			2014-Present	
Mercedes	1997-Present						
Mitsubishi Fuso	1997-Present						
Motor Coach Industries (MCI)		2004-Present	1995-2003				
Peterbilt			1995-2002 (Vehicle can be Ordered as 6-Pin until 2006)	2003-Present	2018 - Present (Optional)		
Prevoist			1995-2003	2004-Present			
Ram	2009-Present						
Sterling		2001-2010	1995-2000				
Suburu	1997-Present						
Tesla							2006-Present
Toyota	1997-Present						
Van Hool			1995-2001	2002-Present			
Volkswagen	1997-Present						
Volvo		2003-2012	1995-2002			2013-Present	
Volvo w/ Cummins or Caterpillar Engine		2003-Present	1995-2002				
Volvo All LD Models	1997-Present						
Western Star			1995-1999	2000-Present	2018-Present		

Click here to view and download the PDF version: [GPSI-5000 Diagnostic Cable Guide](#)