

Link: <https://help.gpsinsight.com/installation-video/gps-3900ie-vpod/> Last Updated: January 8th, 2016

This video walks you through the following steps in the installation process:

1. Locate the vehicles OBD-II port, and ensure proper voltage.
2. Free up existing OBD-II port.
3. Assemble mounting bracket, and connect the OBD-II Pass-Thru Cable to the vehicle's OBD-II port.
4. Mount the replacement OBD-II port, and pull cable through the dash.
5. Install the external antenna, and route the cables.
- INSTALL OPTIONAL ACCESSORIES -
6. Tape off all unused wires and connect the vPOD to harness AUX 1.
7. Locate ignition source and connect 20-pin harness white wire.

Since the publication of this video, steps 6 and 7 of this installation process have changed. Please review the **vPOD White Wire insert** before you install your device.

8. Connect the antenna cables to the device.
9. Connect the harness and mount the device.
10. Connect the vPOD to the OBD-II Pass-Thru Cable.
11. Verify installation, and tamper-proof remaining connections.