


When you click on a vehicle/driver (if assigned) from the map or use the Search Field to locate a vehicle, the Vehicle Card for the selected vehicle/driver displays. With the Vehicle Card, you can see:

- Vehicle ID or name
- Driver (if associated/assigned)
- Address of last reported location
- Details (e.g., vehicle, status, driver, landmark, EV data - if applicable, odometer, engine hours, voltage (if reported), and more)
- Attributes (if applicable)
- Camera events (if applicable)
- Street view of last reported location

Using the Vehicle Card

Link: <https://help.gpsinsight.com/docs/about-the-map-page/available-map-cards/using-the-vehicle-card/> Last Updated: May 9th, 2019

Vehicle details ✕

 **Joe Gosselin**
19071 N Scottsdale Rd, Scottsdale, AZ 85255-9672
Stopped 44 min

Edit Dispatch ⋮

Overview Maintenance Nearby

▼ **Details**

Vehicle
2021 Tesla Model 3

Driver
Joe Gosselin ✕ [Reassign](#)

Landmark
BillsTest

Device Type
GO9

Device Serial Number
[REDACTED]

VIN
[REDACTED]

Charge level 55%	Available range 172 miles
----------------------------	-------------------------------------

Charging status
Not Charging

Electricity used ⓘ
8991.05 kWh

Odometer
[REDACTED]


Using the Vehicle Card Header and Vehicle Card Status Bar, you can quickly manage and monitor individual vehicles in your fleet.

Note. The Driver feature is available with the Driver Management add-on. If you would like to

learn more, please contact your Account Manager.

Vehicle Card Header

Using the Vehicle Card Header of the Vehicle Card, you can edit, follow, and/or isolate a vehicle, create a landmark, send a message or dispatch, copy location data, and view trip history directly from the card.




See [Vehicle Card Header](#) for step-by-step instructions on using the features available from the header.

Vehicle Card Status Bar

From the Status Bar, you can view a general overview of details pertaining to the selected vehicle, maintenance/service information, and nearby assets and landmarks.

Using the Vehicle Card

Link: <https://help.gpsinsight.com/docs/about-the-map-page/available-map-cards/using-the-vehicle-card/> Last Updated: May 9th, 2019



See [Vehicle Card Status Bar](#) for step-by-step instructions on using the features available from the status bar.