

When you click on a vehicle/driver (if assigned) from the map or use the Search Field to locate a vehicle, the Vehicle Card for the selected vehicle/driver displays. With the Vehicle Card, you can see:


- Vehicle ID or name
- Driver (if associated/assigned)
- Address of last reported location
- Details (e.g., vehicle, status, driver, landmark, EV data - if applicable, odometer, engine hours, voltage (if reported), and more)
- Attributes (if applicable)
- Camera events (if applicable)
- Street view of last reported location

# Using the Vehicle Card

Link: <https://help.gpsinsight.com/docs/about-the-map-page/available-map-cards/using-the-vehicle-card/> Last Updated: May 9th, 2019

**Vehicle details** ✕

---

 **Joe Gosselin**  
19071 N Scottsdale Rd, Scottsdale, AZ 85255-9672  
Stopped 44 min

Edit Dispatch ⋮

**Overview** Maintenance Nearby

▼ **Details**

Vehicle  
**2021 Tesla Model 3**

Driver  
Joe Gosselin ✕ [Reassign](#)

Landmark  
**BillsTest**

Device Type  
**GO9**

Device Serial Number  
[REDACTED]

VIN  
[REDACTED]

● Charge level <b>55%</b>	Available range <b>172 miles</b>
------------------------------	-------------------------------------

Charging status  
**Not Charging**

Electricity used ⓘ  
**8991.05 kWh**

Odometer  
[REDACTED]


Using the Vehicle Card Header and Vehicle Card Status Bar, you can quickly manage and monitor individual vehicles in your fleet.

**Note.** The Driver feature is available with the Driver Management add-on. If you would like to

learn more, please contact your Account Manager.

## Vehicle Card Header

Using the Vehicle Card Header of the Vehicle Card, you can edit, follow, and/or isolate a vehicle, create a landmark, send a message or dispatch, copy location data, and view trip history directly from the card.




See [Vehicle Card Header](#) for step-by-step instructions on using the features available from the header.

## Vehicle Card Status Bar

From the Status Bar, you can view a general overview of details pertaining to the selected vehicle, maintenance/service information, and nearby assets and landmarks.

# Using the Vehicle Card

Link: <https://help.gpsinsight.com/docs/about-the-map-page/available-map-cards/using-the-vehicle-card/> Last Updated: May 9th, 2019



See [Vehicle Card Status Bar](#) for step-by-step instructions on using the features available from the status bar.