

## Connecting the Android BYOD to ELD Complete


The ELD Complete solution supports Bring Your Own Device (BYOD) via Bluetooth. Drivers can download the GPS Insight ELD Complete app (Android and iOS compatible) to their mobile device from the [Apple App Store](#) or the [Google Play Store](#). The BYOD solution requires a **GPSI-5000** device installed in the vehicle.

We recommend keeping a sticker, or card, in the vehicle with the serial number of the installed GPS device for easy reference during future driver assignments.


1. Install the ELD Complete app to your device:

- [Apple App Store](#)
- [Google Play Store](#)


2. Log in to the ELD Complete application using valid credentials.



3. Select Tractor and tap **Save**.




4. Enter dash odometer values and tap **Save**.



5. Tap the device, then tap **Continue**.

**Note.** Serial numbers are unique to each truck, please contact your Administrator to confirm your truck's serial number.



6. Ensure all diagnostics pass with values shown in green (see example below), then tap **Continue**.




You are ready to drive.

## Additional Resources

### Disconnecting Bluetooth Vehicle Connection

1. Tap on the hamburger menu from the top-left corner of the application, then tap **Scan Devices**.



2. From the ECM-Linked Devices screen, tap **Scan Devices**.



3. The Connected status (in green) is no longer shown, tap **Continue**.




The screen navigates to the Diagnostic page. All values from this page will be shown in red, which confirms the Bluetooth connection has been disabled.




You can now log out and leave the Bluetooth connection available to the vehicle for the next driver.

## Connecting to Bluetooth While Logged In

1. Tap on the hamburger menu from the top-left corner of the application, then tap **Scan Devices**.



2. Tap on the applicable device, then tap **Continue**.



Link: <https://help.gpsinsight.com/docs/byod-android-device-connection/> Last Updated: September 23rd, 2024

3. Ensure all diagnostics pass (values are shown in green), then tap **Continue**.



You are ready to drive.