

Below are the full lists of events and statuses available in Driver Logs for ELD Flex.

• Status Events

- OffDuty
- Sleeper
- Driving
- OnDuty ND
- WaitingAtSite: Waiting at Well Site (for oilfield/construction exception)

• Remark Events

- Authentication Remark - This is the login to the application by the driver
- Unauthenticate Remark - This is the Logout of the application by the driver
- Co-driver login Remark - Login of a Co-Driver in a Primary Driver's log
- ELD Connection - Connection to the Engine Control Device
- ELD Disconnection - Disconnection of the Engine Control Device
- Switch Vehicle Remark
- Switch Trailer Remark
- Switch Vehicle and Trailer Remark
- Start Hour of the day Changed Remark
- State/Country Border Crossing Remark
- Off Road Remark - When drivers moves to Off Road mode
- On Road Remark - When driver moves back to On Road after Off Road

• Intermediate Events

- Inter: Auto 60 Min Location - Every hour an Intermediate event must be written while in a Driving state to capture location/odometer/engine hours

• **Personal Conveyance and Yard Moves**

- PersonalUse: Personal Use
- YardMoves: Yard Moves
- ClearPU: Clear Personal Use
- ClearYM: Clear Yard Moves

• **Certification**

- Certify - Shows the time that a particular day's log was Certified by the Driver

• **Power Cycle**

- PowerOn: Power on of the vehicle when connected to ECM device
- PowerOff: Power off of the vehicle when connected to ECM device

• **Diagnostic Events & Malfunctions**

- MalPower: Power Malfunction
- MalSync: Engine Synchronization Malfunction
- MalTime: Timing Malfunction
- MalPos: Position Malfunction
- MalRecord: Data Recording Malfunction
- MalTransfer: Data Transfer Malfunction
- MalOther: Other Malfunction
- MalPowerClear: Power Malfunction Cleared
- MalSyncClear: Engine Synchronization Malfunction Cleared
- MalTimeClear: Timing Malfunction Cleared
- MalPosClear: Position Malfunction Cleared

- MalRecordClear: Data Recording Malfunction Cleared
- MalTransferClear: Data Transfer Malfunction Cleared
- MalOtherClear: Other Malfunction Cleared
- DiagPower: Power Diagnostic
- DiagSync: Engine Synchronization Diagnostic
- DiagMissing: Missing Required Data Elements Diagnostic
- DiagTransfer: Data Transfer Diagnostic
- DiagUnidentified: Unidentified Driver Diagnostic
- DiagOther: Other Diagnostic
- DiagPowerClear: Power Diagnostic Cleared
- DiagSyncClear: Engine Synchronization Diagnostic Cleared
- DiagMissingClear: Missing Required Data Elements Diagnostic Cleared
- DiagTransferClear: Data Transfer Diagnostic Cleared
- DiagUnidentifiedClear: Unidentified Driver Diagnostic Cleared
- DiagOtherClear: Other Diagnostic Cleared