

Link: https://help.gpsinsight.com/troubleshooting/driveri-hub-x-faq/ Last Updated: October 27th, 2023

Do you have questions about Driveri Hub-X? That's great because we have answers!

## **Driveri Hub-X Frequently Asked Questions**

Questions	Answers			
What are the requirements for existing camera integration?	Cameras will need to be an analog camera capable of being adapted to the GX12 4 pin Aviation connector. The DriveriHub device supports 480, 720, and 1080.			
Can units manually paired in the Driveri portal be unpaired using the installer app?	No.			
Are OTA (over the air) upgrades available?	Yes, upgrades only happen when the vehicle exceeds 30mph. This process takes approximately 1 minute. If RMA is required, please contact Support.			
How do I confirm the Hub-X is on?	The Hub-X, when fully wired and connected, will power on with ignition. To determine if the Hub-X is on, look for the 4 LED's on the panel opposite to the cable connections. The PWR and SD Card LED's will glow green, and the ERR LED will blink red. This is normal operation. (ERR Red LED indicates device is recording and working properly when blinking)  ERR  NET  PWR  SD			
How do you troubleshoot a non-working camera?	Please see Driveri-Hub-X-Troubleshooting-Guide for a troubleshooting guide.			
What does each LED signify?	Please refer to the LED State table below.			

## **Driveri Hub-X FAQ**



Link: https://help.gpsinsight.com/troubleshooting/driveri-hub-x-faq/ Last Updated: October 27th, 2023

Questions	Answers			
How do I know if a camera should be installed on the right side, left side, or rear of the asset?	The Driveri external cameras have a model number and SKU on the boxes they come in and the cameras themselves have the model number. Please use the following list to identify the installation area:			
tile asset:	<ul> <li>Left Side Camera: FL-750L, SKU NDSQ720PL</li> <li>Right Side Camera: FL-750R, NDSQ720PR</li> <li>Rear Facing Camera: FL-750, SKU NDSQ720PC</li> <li>Internal "Round" Camera: FL-MC-001, SKU NDR720PA</li> </ul>			
	3, 10 (20 MC)			
	A, and tight with the state of			
	AND TO SECONDARY OF THE PROPERTY OF THE PROPER			

#### **LED State**

LED 1	ERR	Red - Blink	Connected to Wi-Fi network
LED 2	NET	No glow	Reserved for future use
LED 3	PWR	Green - Solid	Device Power ON indicator
LED 4	SD	Green - Solid	SD card installed
LED 5	IR	No glow	Reserved for installers – IR activity while using remote

### **Hub-X Storage**

The storage information below is based on use of 720p external cameras.

Driveri Camera Storage Hours 1 Ext Cam 2 Ext Cam (Standalone Storage (hr) (hr)	3 Ext Cam Storage (hr)	4 Ext Cam Storage (hr)
--	------------------------------	------------------------------

# **Driveri Hub-X FAQ**



Link: https://help.gpsinsight.com/troubleshooting/driveri-hub-x-faq/ Last Updated: October 27th, 2023

Driveri Camera	Storage Hours (Standalone Driveri)	1 Ext Cam Storage (hr)	2 Ext Cam Storage (hr)	3 Ext Cam Storage (hr)	4 Ext Cam Storage (hr)
D-210	50	50	50	50	50
D-215	100	100	100	100	100
D-410	Up to 100	Up to 100	Up to 100	Up to 100	Up to 100
D-430	Up to 100	Up to 100	Up to 100	Up to 100	Up to 100