


Link: <https://help.gpsinsight.com/docs/about-integration/navistar-tsp/> Last Updated: August 18th, 2016

The following process is designed for Navistar dealers.

► **To configure OnCommandConnection:**


1. Log into the **Dealer portal**.



1. From the Register Vehicles page, locate the serial number of the device.
 - If you find it on this page, it indicates that the device has already been associated with a VIN and you can continue.


VIN	Serial	Account	Last Reported
5FNRL38437B4	4531009	[Provider]	02/03/2016 11:00:01
5FNRL3848780	4531009	[Provider]	02/03/2016 13:07:05
1C4SDJCT5FC8	4542042	[Provider]	09/25/2015 20:03:35

- If you cannot find the serial number of the device on this page, click the **Unregistered** link to register it.



1. Log into the [Navistar OnCommandCenter](#).

If you do not have a dealer account, you must **enroll**. When your account is created, your information appears under Telematic Account Information:



1. After logging into the OnCommandCenter, click the **Vehicles** menu.

Vehicles start appearing within 48 hours after the account has been set up and verified. Column names include: VIN, Chassis, UnitNo, FirstScan, LastScan, Latest Scanner, Year, Model, and Make.

All Vehicles
Add Vehicles

- ✓ Account Info
- ✓ Vehicles
- ✓ Users
- ! Dealers
- ✓ Telematic
- ^ Your Profile

VIN Search

Filter By:	VIN / Chassis	⌵
Order Results By:	VIN_9,Chassis,Unit	⌵
Search By Text:	<input style="width: 80%;" type="text"/>	<input type="button" value="Search"/>

	VIN9	Chassis	UnitNo	FirstScan	LastScan
Edit Delete	1GBE5	6F422045	108	8/24/2015 10:48:34 PM	2/3/2016 7:35:4
Edit Delete	1GBE5	9F406405	401	8/24/2015 10:48:29 PM	2/3/2016 7:34:5
Edit Delete	1GDL7	3F509508	363	8/24/2015 10:48:29 PM	2/3/2016 7:35:4

1. **Contact us** when this process is complete, and we can enable the data flow on the GPS side.